

SAGP-865EVG

SOCKET 478 PENTIUM 4
with Ethernet & USB 2.0

User Manual

Version 1.1

September 29, 2003



@Copyright 2003 by ICP Electronics Inc. All Rights Reserved.

Copyright Notice

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Trademarks

SAGP-865EVG is a registered trademark of ICP Electronics Inc.; IBM PC is a registered trademark of International Business Machines Corporation. INTEL is a registered trademark of INTEL Corporation. Award is registered trademarks of American Megatrends Inc., Other product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Support

Any questions regarding the content of this manual or related issues can be e-mailed to us directly at:

SUPPORT@IEI.COM.TW

Table of Contents

CHAPTER 1	INTRODUCTION	1
2.1	SPECIFICATIONS	2
2.2	PACKAGE CONTENTS	5
CHAPTER 2	INSTALLATION	6
2.3	LAYOUT	6
2.4	DIMENSIONS (UNIT : MM)	8
2.5	UNPACKING PRECAUTIONS	9
2.6	COMPACT FLASH MASTER/SLAVE FUNCTION SETTING	10
2.7	CLEAR CMOS SETUP	10
CHAPTER 3	CONNECTION	11
3.1	AUDIO CONNECTOR	12
3.2	VGA CONNECTOR	13
3.3	PCI E-IDE DISK DRIVE CONNECTOR	14
3.4	PARALLEL PORT CONNECTOR	15
3.5	ATX POWER BUTTON CONNECTOR	16
3.6	USB PORT CONNECTOR	16
3.7	SERIAL PORT	17
3.8	KEYBOARD/MOUSE CONNECTOR	17
3.9	IRDA INFRARED INTERFACE PORT	18
3.10	FAN CONNECTOR	18
3.11	EXTERNAL SWITCHES AND INDICATORS	19
3.12	LAN CONNECTOR	19
3.13	SERIAL ATA CONNECTOR	20
3.14	FLOPPY CONNECTOR	20
3.15	COMPACT FLASH STORAGE CARD SOCKET	21
CHAPTER 4	AWARD BIOS SETUP	22
4.1	INTRODUCTION	22
4.2	STARTING SETUP	22
4.3	USING SETUP	23
4.4	MAIN MENU	24
4.5	STANDARD CMOS SETUP	27

4.6	ADVANCED BIOS FEATURES	30
4.7	ADVANCED CHIPSET FEATURES	34
4.8	INTEGRATED PERIPHERALS	37
4.9	POWER MANAGEMENT SETUP.....	42
4.10	PNP/PCI CONFIGURATION SETUP.....	46
4.11	PC HEALTH STATUS.....	48
4.12	FREQUENCY/VOLTAGE CONTROL.....	49
4.13	LOAD FAIL-SAFE DEFAULTS	50
4.14	LOAD OPTIMIZED DEFAULTS	50
4.15	SET PASSWORD.....	51
4.16	EXIT SELECTING	52
APPENDIX A. WATCHDOG TIMER		53
APPENDIX B. ADDRESS MAPPING		55
APPENDIX C.		
HOW TO UPGRADE A NEW BIOS.....		57
APPENDIX D. AGP SLOT		60
APPENDIX E. INSTALL MEMORY MODULES..		61

Chapter 1 Introduction

SAGP-865EVG is an AGP/PCI form factor board to work with a high performance processor. It is equipped with advanced high performance multi-mode I/O and designed for the system manufacturers, integrators, or VARs who want to provide all the performance, reliability, and quality at a reasonable price.

Its AGP interface supports 0.8V/1.5V signaling with 8X/4X data transferring, but it does not support any AGP-card of 3.3V. The integrated graphics controller provides 3D, 2D, and display capabilities.

SAGP-865EVG supports one or two 64-bit wide DDR data channels. The available bandwidth is up to 2.7GB/s for single-channel mode and 5.4GB/s for dual-channel mode. The CSA interface connects to the GMCH with a Gigabit Ethernet controller.

The built-in ICH5 provides 10/100 Fast Ethernet LAN connection. It's a fully integrated 10BASE-T/100BASE-TX LAN solution with high performance networking functions and low power consumption.

For the application that needs high speed serial transmission, the SAGP-865EVG provides USB2.0 for an alternative choice. The high speed USB2.0 host controller implements an ECHI interface that provides 480Mb/s bandwidth.

This PIAGP CPU card must be installed on PCIAGP/PXAGP series backplanes made by IEI. If onboard ISA interface is required, please be sure to install PISA-KIT01 daughter board on the specific socket on the backplane before ISA cards are installed so the system can work properly.

2.1 Specifications

CPU(PGA 478)	Intel Pentium 4 Processor, supports 400/533/800 MHz PSB (SET BY BIOS)
Bus interface	AGP/PCI bus, PICMG compliant
Bus speed	PCI: 33MHz
DMA channels	7
Interrupt levels	15
Chipset	INTEL 865G / ICH5
RAM memory	Two 184-pin DIMM sockets support DDR333/400 SDRAM .Support one or two 64-bit wide DDR data channels. The max. Memory is up to 2GB.
Ultra DMA 100 IDE interface	Up to four PCI Enhanced IDE hard drives. The Ultra DMA 100 IDE can handle data transfer up to 100MB/s. Compatible with existing ATA IDE specifications its best advantage, so there is no need to do any changes for users' current accessories.
Floppy disk drive interface	Supports up to two floppy disk drives, 5.25"(360KB and 1.2MB) and/or 3.5" (720KB, 1.44MB, and 2.88MB)
Serial ports	Two RS-232 ports with 16C550 UART (or compatible) with 16-byte FIFO buffer. Support up to 115.2Kbps. Ports can be individually configured to COM1, COM2 or disabled.
Bi-directional parallel port	Configurable to LPT1, LPT2, LPT3 or disabled. Supports EPP/ECP/SPP

Hardware monitor	Built-in to monitor power supply voltage and fan speed status
IrDA port	Supports Serial Infrared(SIR) and Amplitude Shift Keyed IR(ASKIR) interface
USB 2.0/1.1 port	Supports 7 USB 2.0/1.1 ports for future expansion
Watchdog timer	Software Programmable Reset generated when CPU does not periodically trigger the timer.
Serial ATA	Supports Two independent serial ATA channels. Serial ATA generation 1 transfer rate of 150MB/s (Note)
Ethernet	The CSA interface connectors GMCH with a 82547EI Gigabit Ethernet controller. It's to Support full 100/1000-bast-T Ethernet ICH5 integrated fast Ethernet MAC features an IEEE802.3 and 802.3x compliant MAC supporting full duplex 10-base-T,100-bast-T Ethernet.
Keyboard and PS/2 mouse connector	A 6-pin mini DIN connector is located on the mounting bracket for easy connection to a keyboard or PS/2 mouse. For alternative application, a keyboard and a PS/2 mouse pin header connector are also available on board.
Audio	AC'97 Audio CODEC
Compact flash	It can be used with a passive adapter (True IDE Mode) in a Type I/II Socket.

Power consumption	PENTIUM4:3.0GHz, 512B DDR400 DDR-SDRAM +12V@ 7.5A ,+5V@7A ,-12V@0.5A Recommended : 350-watt power supply or higher
Operating temperature	0° ~ 55° C (*CPU needs Cooler & silicone heat sink paste*)

WARNING :

1. Never run the processor without the heat sink (Cooler).
2. Please use ATX-12V Power Connector (CN3) to provide power to the CPU.

2.2 Package Contents

SAGP-865EVG package includes the following items:

- One SAGP-865EVG Single Board Computer
- One RS-232 & Printer Cable with bracket
- One FDD cable
- TWO PATA IDE cables.
- TWO SATA IDE cables.
- ONE SATA Power cable.
- One AUDIO cable.
- One ATX-12V cable.
- One keyboard and mouse Y-Adapter cable.
- One Driver CD
- One User manual


If any of these items are missing or damaged, contact the dealer from whom you purchased this product. Save the shipping materials and carton in case you want to ship or store the product in the future.

Chapter 2 Installation


This chapter describes how to install the SAGP-865EVG. At first, the layout of SAGP-865EVG is shown, and the unpacking information that you should be careful with is described. The jumpers and switch settings for the SAGP-865EVG 's configuration, such as CPU type selection, system clock setting, and watchdog timer, are also included.

2.3 Layout

<This area is intentionally left blank>



2.4 Dimensions (Unit : mm)



2.5 Unpacking Precautions

Some components on SAGP-865EVG are very sensitive to static electric charges and can be damaged by a sudden rush of power. To protect it from unintended damage, be sure to follow these precautions:

- ✓ Ground yourself to remove any static charge before touching your SAGP-865EVG. You can do it by using a grounded wrist strap at all times or by frequently touching any conducting materials that is connected to the ground.
- ✓ Handle your SAGP-865EVG by its edges. Don't touch IC chips, leads or circuitry if not necessary.
- ✓ Do not plug any connector or jumper while the power is on.

2.6 Compact Flash Master/Slave Function Setting

- **JP1: Compact Flash Master/Slave Function Setting**
Short 1 - 2 pin , Compact Flash is Master

JP1	DESCRIPTION
Close	Master
Open	Slave

2.7 Clear CMOS Setup

To clear the CMOS Setup (for example if you forget the password, you should clear the CMOS and then re-set the password), please close the JP2 (2-3) for about 3 seconds, then open it once more. This will set the CMOS back to normal operation mode.

- **JP2: Clear CMOS Setup**

JP2	DESCRIPTION
1-2 (default)*	Keep CMOS Setup (Normal Operation)
Short 2-3	Clear CMOS Setup

Note: All shaded rows in tables of this manual are the default settings for the SAGP-865EVG.

Chapter 3 Connection

This chapter describes how to connect peripherals, switches and indicators to the SAGP-865EVG.

Table of Connections

Label	Function
IDE1 & IDE2	Ultra ATA100 Primary & Secondary IDE connectors
FDD1	Floppy connector
LPT1	Parallel port connector
COM1 & COM2	Serial port connectors
CF1	Compact Flash Storage Card Type II connector
IR1	IRDA infrared interface port
USB1	USB port connector
USB2	USB dual port connector
USB3	USB dual port connector
USB4	USB dual port connector
LAN1 & LAN2	LAN RJ45 connector
KB/MS1	6-pin Mini-Din Keyboard & Mouse connector
FAN1 & FAN2	FAN connector
SATA1 & SATA2	Serial ATA connectors
CN1	Audio CD in connector
CN2	Audio connector
CN3	ATX +12V Power connector
CN4	External switches and indicators
PW1	ATX Power Button connector

3.1 Audio Connector

The onboard AC'97 CODEC supports several audio functions. The audio connectors are described below.

- **CN2: Audio connector (Speaker out, Line out, Line in, MIC in)**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	Speaker out (Left)	2	Speaker Out (Right)
3	GROUND	4	GROUND
5	Line Out (Left)	6	Line Out (Right)
7	Line In (Left)	8	Line In (Right)
9	GROUND	10	GROUND
11	MIC In	12	GROUND

- **CN1 : Audio CD In connector**

PIN	DESCRIPTION
1.	CD SIGNAL (LEFT)
2.	GROUND
3.	GROUND
4.	CD SIGNAL (RIGHT)

3.2 VGA Connector

- **VGA1: 15-pin Female Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RED	2	GREEN
3	BLUE	4	NC
5	GROUND	6	GROUND
7	GROUND	8	GROUND
9	VCC / NC	10	GROUND
11	NC	12	DDC DAT
13	HSYNC	14	VSYNC
15	DDCCLK		

3.3 PCI E-IDE Disk Drive Connector

You can attach up to four IDE(Integrated Device Electronics) devices.

IDE1 : Primary IDE Connector

IDE2 : Secondary IDE Connector

• IDE1 & IDE2 : IDE Interface Connector

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RESET#	2	GROUND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GROUND	20	N/C
21	DRQ	22	GROUND
23	IOW#	24	GROUND
25	IOR#	26	GROUND
27	CHRDY	28	REV. PULL LOW
29	DACK	30	GROUND-DEFAULT
31	INTERRUPT	32	N/C
33	SA1	34	N/C
35	SA0	36	SA2
37	HDC CS0#	38	HDC CS1#
39	HDD ACTIVE#	40	GROUND

3.4 Parallel Port Connector

Usually, a printer is connected to the parallel port. The SAGP-865EVG includes an on-board parallel port, accessed via a 26-pin flat-cable connector LPT1.

• LPT1 : Parallel Port Connector

PIN	DESCRIPTION	PIN	DESCRIPTION
1	STROBE#	2	DATA 0
3	DATA 1	4	DATA 2
5	DATA 3	6	DATA 4
7	DATA 5	8	DATA 6
9	DATA 7	10	ACKNOWLEDGE
11	BUSY	12	PAPER EMPTY
13	PRINTER SELECT	14	AUTO FORM FEED #
15	ERROR#	16	INITIALIZE
17	PRINTER SELECT LN#	18	GROUND
19	GROUND	20	GROUND
21	GROUND	22	GROUND
23	GROUND	24	GROUND
25	GROUND	26	NC

3.5 ATX Power Button Connector

- **PW1: ATX Power Button Connector**

PIN	DESCRIPTION
1	PWRBTN
2	GROUND

3.6 USB Port Connector

The SAGP-865EVG is equipped with Four USB(Version. 2.0) ports for the future new I/O bus expansion.

- **USB1 : 1 ports USB Connector**

PIN	DESCRIPTION
1.	VCC
2.	DATA0-
3.	DATA0+
4.	GROUND

- **USB2, USB3, USB4 : 2 ports USB Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1.	VCC	2.	GROUND
3.	DATA0-	4.	DATA1+
5.	DATA0+	6.	DATA1-
7.	GROUND	8.	VCC

3.7 Serial Port

The SAGP-865EVG offers Two high speed NS16C550 compatible UART's with 16-byte Read/Receive FIFO serial ports.

- **COM1,COM2: 10Pin Serial Port Connector**

PIN	DESCRIPTION
1	DATA CARRIER DETECT (DCD)
2	RECEIVE DATA (RXD)
3	TRANSMIT DATA (TXD)
4	DATA TERMINAL READY (DTR)
5	GROUND (GND)
6	DATA SET READY (DSR)
7	REQUEST TO SEND (RTS)
8	CLEAR TO SEND (CTS)
9	RING INDICATOR (RI)
10	GROUND (GND)

3.8 Keyboard/Mouse Connector

The SAGP-865EVG has a 6-pin DIN keyboard/mouse connector

- **KB/MS1 :Mini DIN Keyboard/Mouse Connector**

PIN	DESCRIPTION
1	KEYBOARD DATA
2	MOUSE DATA
3	GROUND
4	+5V
5	KEYBOARD CLOCK
6	MOUSE CLOCK

3.9 IrDA Infrared Interface Port

The SAGP-865EVG comes with an integrated IrDA port which supports either a Serial Infrared(SIR) or an Amplitude Shift Keyed IR(ASKIR) interface.

• IR1: IrDA Connector

PIN	DESCRIPTION
1	VCC
2	NC
3	IR-RX
4	Ground
5	IR-TX
6	CIRRX

3.10 Fan Connector

The SAGP-865EVG also has a CPU with cooling fan connector and chassis fan connector, which can supply 12V/500mA to the cooling fan. There is a "rotation" pin in the fan connector, which transfers the fan's rotation signal to the system BIOS in order to recognize the fan speed. Please note that only specific fans offer a rotation signal.

• FAN1,FAN2 : CPU Fan Connector

PIN	DESCRIPTION
1	Ground
2	+12V
3	Rotation Signal

3.11 External Switches and Indicators

There are several external switches and indicators for monitoring and controlling your CPU board. All functions are in the CN4 connector.

• CN4 : Pin Assignment and Functions

FUNCTION	PIN	DESCRIPTION
BUZZER	2	BUZZER-
	4	NC
	6	NC
	8	VCC
RESET	10	RESET
	12	GROUND
HDD LED	9	IDE_LED+
	11	IDE_LED-
POWER LED	1	LED+
	3	LED-(GROUND)
RESERVE	5	GROUND
	7	NC

3.12 LAN Connector

The SAGP-865EVG is equipped with Ethernet Controllers 10/100Mbps, which are connected to the LAN via an RJ45 LAN connector. The pin assignments are as follows:

• LAN1,LAN2 : RJ45 Connector (10/100)

PIN	DESCRIPTION	PIN	DESCRIPTION
1	TX+	7	N/C
2	TX-	8	N/C
3	RX+	9	Speed +
4	N/C	10	Speed -
5	N/C	11	Active/LINK +
6	RX-	12	Active/LINK -

3.13 Serial ATA Connector

The SAGP-865EVG provide 2 Serial ATA ports to connect with Serial ATA devices.

- **SATA1, SATA2 : Serial ATA Connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	S_TXP	3	S_RXN
2	S_TXN	4	S_RXP

3.14 Floppy Connector

The SAGP-865EVG board is equipped with a 34-pin daisy-chain drive connector cable.

- **FDD1 : Floppy Connector**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GROUND	2	RWC0-
3	GROUND	4	NC
5	GROUND	6	RWC1-
7	GROUND	8	INDEX-
9	GROUND	10	MO-A
11	GROUND	12	DS-B
13	GROUND	14	DS-A
15	GROUND	16	MO-B
17	GROUND	18	DIR-
19	GROUND	20	STEP-
21	GROUND	22	WD-
23	GROUND	24	WGATE-
25	GROUND	26	TRK0-
27	GROUND	28	WP-
29	GROUND	30	RDATA-
31	GROUND	32	HEAD-
33	GROUND	34	DSKCHG-

3.15 Compact Flash Storage Card Socket

The SAGP-865EVG configures Compact Flash Storage Card in IDE Mode. This type II Socket is compatible with IBM Micro Drive.

• **CF1: Compact Flash Storage Card Socket pin assignment**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GROUND	26	PULL DOWN
2	D3	27	D11
3	D4	28	D12
4	D5	29	D13
5	D6	30	D14
6	D7	31	D15
7	CS1#	32	CS3#
8	N/C	33	N/C
9	GROUND	34	IOR#
10	N/C	35	IOW#
11	N/C	36	VCC
12	N/C	37	IRQ15
13	VCC	38	VCC
14	N/C	39	MASTER/SLAVE
15	N/C	40	N/C
16	N/C	41	RESET#
17	N/C	42	IORDY
18	A2	43	N/C
19	A1	44	VCC
20	A0	45	ACTIVE#
21	D0	46	PDIAG#
22	D1	47	D8
23	D2	48	D9
24	N/C	49	D10
25	PULL DOWN	50	GROUND

Chapter 4 Award BIOS Setup

4.1 Introduction

This chapter discusses the Setup program written in the BIOS. It will give you a step-by-step guidance to configure your system. The user-defined configuration is then stored in battery-backed CMOS RAM, which retains the customized information while the power is off.

4.2 Starting Setup

The BIOS is immediately active when you turn on the computer. While the BIOS is in control, the Setup program can be activated in one of two ways:

1. By pressing immediately after switching the system on, or
2. By pressing the key when the following message appears at the bottom of the screen during POST (Power On Self-Test):

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to...

PRESS F1 TO CONTINUE, DEL TO ENTER SETUP


4.3 Using Setup

In general, you can use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more details about how to navigate in the Setup program using the keyboard.

Key	Function
Up Arrow	Move to the previous item
Down Arrow	Move to the next item
Left Arrow	Move to the item on the left (menu bar)
Right Arrow	Move to the item on the right (menu bar)
Esc	Main Menu: Quit without saving changes Submenus: Exit Current page to the next higher level menu
Move Enter	Move to the item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
Esc key	Main Menu -- Quit and save no changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1 key	General help on Setup navigation keys
F5 key	Load previous values from CMOS
F6 key	Load the fail-safe defaults from BIOS default table
F7 key	Load the optimized defaults
F10 key	Save all the CMOS changes and exit

4.4 Main Menu

Once you enter the AwardBIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to go through the items and press <Enter> to accept and enter the sub-menu.



Note that a brief description of each highlighted selection appears at the bottom of the screen.

Setup Items

The main menu includes the following main setup categories. Recall that some systems may not include all entries.

Standard CMOS Features

Use this menu for basic system configuration. See Section 4.5 for the details.

Advanced BIOS Features

Use this menu to set the Advanced Features available on your system. See Section 4.6 for the details.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance. See section 4.7 for the details.

Integrated Peripherals

Use this menu to configure your settings for integrated peripherals. See section 4.8 for the details.

Power Management Setup

Use this menu to configure your settings for power management. See section 4.9 for the details.

PnP / PCI Configuration

This entry appears if your system supports PnP / PCI. See section 4.10 for the details.

PC Health Status

Use this menu to monitor your hardware. See section 4.11 for details.

Frequency/Voltage Control

Use this menu to configure your settings for frequency/voltage control. See section 4.12 for the details.

Load Fail-Safe Defaults

Use this menu to load the BIOS default values for the minimal/stable performance for your system to operate. See section 4.13 for the details.

Load Optimized Defaults

Use this menu to load the BIOS default values that are factory settings for optimal performance system operations. While Award has designed the custom BIOS to maximize

performance, the factory has the right to change these defaults to meet their needs. See section 4.14 for the details.

Set Password

Use this menu to set Passwords. See section 4.15 for the details.

Save & Exit Setup

Save CMOS value changes to CMOS and exit setup. See section 4.16 for the details.

Exit Without Save

Abandon all CMOS value changes and exit setup. See section 4.15 for the details.

4.5 Standard CMOS Setup

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
Standard CMOS Features		
Date (mm:dd:yy)	Aug 6 2003	Menu Level ▶
Time (hh:mm:ss)	13 : 35 : 53	Change the day, month, year and century
▶ IDE Channel 0 Master	[None]	
▶ IDE Channel 0 Slave	[None]	
▶ IDE Channel 1 Master	[None]	
▶ IDE Channel 1 Slave	[None]	
Drive A	[1.44M, 3.5 in.]	
Drive B	[None]	
Video	[EGA/UGA]	
Halt On	[All , But Keyboard]	

↑↓←→:Move Enter:Select +/-/PU/PD:Ualue F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Item	Options	Description
Date	MM DD YYYY	Set the system date.
Time	HH : MM : SS	Set the system time
IDE Primary Master	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
IDE Secondary	Options are in its sub menu (described in Table 3)	Press <Enter> to enter the sub menu of detailed options
Drive A Drive B	None 360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in	Select the type of floppy disk drive installed in your system
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/Key	Select the situation in which you want the BIOS to stop the POST process and notify you
Base Memory	N/A	Displays the amount of conventional memory detected during boot up
Extended Memory	N/A	Displays the amount of extended memory detected during boot up
Total Memory	N/A	Displays the total memory available in the system


IDE HDD Auto-detection	Press Enter	Press Enter to auto-detect the HDD on this channel. If detection is successful, it fills the remaining fields on this menu.
IDE Primary Master	None Auto Manual	Selecting 'manual' lets you set the remaining fields on this screen. Selects the type of fixed disk. "User Type" will let you select the number of cylinders, heads, etc. Note: PRECOMP=65535 means NONE !
Capacity	Auto Display your disk drive size	Disk drive capacity (Approximated). Note that this size is usually slightly greater than the size of a formatted disk given by a disk checking program.
Access Mode	CHS LBA Large Auto	Choose the access mode for this hard disk

4.6 Advanced BIOS Features

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing and security.

Virus Warning

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep.



Enabled	Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.
Disabled	No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

Hard Disk Boot Priority

This setting is to select hard disk boot priority

CPU L1 & L2 Cache

These two categories speed up memory access. However, it depends on CPU/chipset design.

Enabled	Enable cache
Disabled	Disable cache

Hyper-Threading Technology

This setting is to enable or disable hyper threading CPU support

Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power up the computer. If it is set to Enable, BIOS will shorten or skip some check items during POST.

Enabled	Enable quick POST
Disabled	Normal POST

First/Second/Third/Other Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items.

The Choice: Floppy, LS120, HDD0-3, SCSI, CDROM, ZIP 100 , LAN, Disabled.

Swap Floppy Drive

If the system has two floppy drives, you can swap the logical drive name assignments.

The Choice: Enabled/Disabled.

Boot Up Floppy Seek

Seeks disk drives during boot up. Disabling speeds boot up.

The Choice: Enabled/Disabled.

Boot Up NumLock Status

Select power on state for NumLock.

The Choice: On/Off.

Gate A20 Option

Select if chipset or keyboard controller should control GateA20.

Normal	A pin in the keyboard controller controls GateA20
Fast	Lets chipset control GateA20

Typematic Rate Setting

Key strokes repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be selected.

The Choice: Enabled/Disabled.

Typematic Rate (Chars/Sec)

Sets the number of times a second to repeat a key stroke when you hold the key down.

The Choice: 6, 8, 10, 12, 15, 20, 24, 30.

Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke.

The Choice: 250, 500, 750, 1000.

Security Option

Select whether the password is required every time the system boots or only when you enter setup.

System	The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
Setup	The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

Note: To disable security, select PASSWORD SETTING at Main Menu and then you will be asked to enter password. Do not type anything and just press <Enter>, it will disable security. Once the security is disabled, the system will boot and you can enter Setup freely.

OS Select For DRAM > 64MB

Select the operating system that is running with greater than 64MB of RAM on the system.

The Choice: Non-OS2, OS2.

Small Logo(EPA) Show

Disabled/Enabled Small Logo(EPA) Show

4.7 Advanced Chipset Features

Phoenix - AwardBIOS CMOS Setup Utility		
Advanced Chipset Features		
		Item Help
DRAM Timing Selectable	[By SPD]	
CAS Latency Time	[2]	
Active to Precharge Delay	[8]	Menu Level ▶
DRAM RAS# to CAS# Delay	[4]	
DRAM RAS# Precharge	[4]	
Memory Frequency For	[Auto]	
System BIOS Cacheable	[Enabled]	
Video BIOS Cacheable	[Disabled]	
Memory Hole At 15M-16M	[Disabled]	
Delay Prior to Thermal	[16 Min]	
AGP Aperture Size (MB)	[128]	
Init Display First	[PCI Slot]	
On-Chip UGA	[Enabled]	
On-Chip Frame Buffer Size	[16MB]	
Boot Display	[Auto]	

↑↓←→:Move Enter:Select +/-/PU/PD:Ualue F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and the external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. It must be stated that these items should never need to be altered. The default settings have been chosen because they provide the best operating conditions for your system.

DRAM Timing Selectable

The first chipset settings deal with CPU access to dynamic random access memory (DRAM). The default timings have been carefully chosen and should only be altered if data is being lost. Such a scenario might well occur if your system had mixed speed DRAM chips installed so that greater delays may be required to preserve the integrity of the data held in the slower memory chips.

CAS Latency Time

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing.

The Choice: 1.5 , 2, 2.5 , 3

DRAM RAS# to CAS# Delay

This field lets you insert a timing delay between the CAS and RAS strobe signals, used when DRAM is written to, read from, or refreshed. Fast gives faster performance; and Slow gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

The Choice: 2, 3.

DRAM RAS# Precharge

If an insufficient number of cycles is allowed for the RAS to accumulate its charge before DRAM refresh, the refresh may be incomplete and the DRAM may fail to retain data. Fast gives faster performance; and Slow gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

The Choice: 2, 3.

DRAM Frequency For

This field displays the capability of the memory modules that you are using either H/W TRAP.

The Choice: Auto, DDR266, DDR333, DDR400.

System BIOS Cacheable

Selecting Enabled allows caching of the system BIOS ROM at F0000h-FFFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result.

The Choice: Enabled, Disabled.

Video BIOS Cacheable

Select Enabled allows caching of the video BIOS , resulting in better system performance. However, if any program writes to this memory area, a system error may result.

The Choice: Enabled, Disabled.

Memory Hole At 15M-16M

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements.

The Choice: Enabled, Disabled.

AGP Aperture Size (MB)

Select the on-chip video window size for VGA drive use.

The Choice: 4MB, 8MB, 16MB, 32MB, 64MB, 128MB, 256MB

On-chip VGA

Enabled/Disabled On-chip VGA

4.8 Integrated Peripherals

Phoenix - AwardBIOS CMOS Setup Utility		
Integrated Peripherals		
▶ OnChip IDE Device	[Press Enter]	Item Help
▶ Onboard Device	[Press Enter]	Menu Level ▶
▶ SuperIO Device	[Press Enter]	
Watch Dog Timer Unit	[Second]	
↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Phoenix - AwardBIOS CMOS Setup Utility		
OnChip IDE Device		
IDE HDD Block Mode	[Enabled]	Item Help
On-Chip Primary PCI IDE	[Enabled]	Menu Level ▶▶
IDE Primary Master PIO	[Auto]	
IDE Primary Slave PIO	[Auto]	
IDE Primary Master UDMA	[Auto]	
IDE Primary Slave UDMA	[Auto]	
On-Chip Secondary PCI IDE	[Enabled]	
IDE Secondary Master PIO	[Auto]	
IDE Secondary Slave PIO	[Auto]	
IDE Secondary Master UDMA	[Auto]	
IDE Secondary Slave UDMA	[Auto]	
SATA Mode	[IDE]	
On-Chip Serial ATA	[Auto]	
Serial ATA Port0 Mode	[Primary Master]	
If your IDE hard drive supports block mode select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support		
↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Phoenix - AwardBIOS CMOS Setup Utility		
Onboard Device		
USB Controller	[Enabled]	Item Help
USB 2.0 Controller	[Enabled]	
USB Keyboard Support	[Enabled]	Menu Level ▶▶
AC97 Audio	[Auto]	
182562ET LAN (10/100M)	[Enabled]	
CSA LAN (Giga-LAN)	[Enabled]	

↑↓←→: Move Enter: Select +/~/PU/PD: Uvalue F10: Save ESC: Exit F1: General Help
 F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Phoenix - AwardBIOS CMOS Setup Utility		
SuperIO Device		
POWER ON Function	[BUTTON ONLY]	Item Help
KB Power ON Password	[Enter]	
Hot Key Power ON	[Ctrl-F1]	Menu Level ▶▶
Onboard FDC Controller	[Enabled]	
Onboard Serial Port 1	[3F8/IRQ4]	
Onboard Serial Port 2	[2F8/IRQ3]	
UART Mode Select	[Normal]	
RxD , TxD Active	[Hi,Lo]	
IR Transmission Delay	[Enabled]	
UR2 Duplex Mode	[Half]	
Use IR Pins	[IR-Rx2Tx2]	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[EPP1.7]	
EPP Mode Select	[3]	
ECP Mode Use DMA	[Off]	
PWRON After PWR-Fail	[Off]	

↑↓←→: Move Enter: Select +/~/PU/PD: Uvalue F10: Save ESC: Exit F1: General Help
 F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

On-Chip Primary/Secondary PCI IDE

The integrated peripheral controller contains an IDE interface with support for two IDE channels. Select Enabled to activate each channel separately.

The Choice: Enabled, Disabled.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

The Choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

IDE Primary/Secondary Master/Slave UDMA

Ultra DMA-33/66 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA-33/66, select Auto to enable BIOS support.

The Choice: Auto, Disabled.

On-Chip Serial ATA

- [Disable] : Disable SATA controller.
- [Combined] : SATA and PATA are combined. Max. of 2 IDE drivers in each channel.
- [Enhanced] : Enhanced both SATA and PATA. Max. of 6 IDE drivers are supported.
- [SATA only] : SATA is operating in legacy mode.

USB Controller

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have USB peripherals.

The Choice: Enabled, Disabled.

USB Keyboard Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard.

The Choice: Enabled, Disabled.

AC97 Audio

This item allows you to decide to enable/disable the ALC202A chipset

The Choice: Auto, Disabled.

I82562ET LAN (10/100M)

This item allows you to decide to enable/disable the I82562ET chipset

The Choice: Enabled, Disabled.

CSA LAN (Giga-LAN)

This item allows you to decide to enable/disable the 82547EI chipset

The Choice: Enabled, Disabled.

Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you wish to use it. If you install and-in FDC or the system has no floppy drive, select Disabled in this field.

The Choice: Enabled, Disabled

Onboard Serial Port 1/Port 2

Select an address and corresponding interrupt for the first and second serial ports.

The Choice: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled,

Auto

UART Mode Select

Select a serial port 2 operation mode.

The Choice: Normal, IrDA, ASKIR, SCR

Onboard Parallel Port

Select an address and corresponding interrupt for the parallel ports.

The Choice: 378/IRQ7, 278/IRQ5, 3BC/IRQ7, Disabled,

Parallel Port Mode

Select a parallel operation mode.

The Choice: SPP, EPP, ECP, ECP+EPP


Watchdog Timer Unit Select

Select the Watchdog Timer unit.

The Choice: Second, Minute

4.9 Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy while operating in a manner consistent with your own style of computer use.



Power-Supply Type

Select the Power-Supply Type.

The Choice: ATX, AT Power Supply.

ACPI Function

This feature is switch of ACPI function. Configuration options: Enable/Disable.

ACPI Suspend Type

This feature is switch of POS (S1) or STR (S3) function. Configuration options: [S1<POS>] [S3<STR>] [S1&S3].

Power Management

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

Min. Power Saving	Minimum power management. Doze Mode = 1 hr. Standby Mode = 1 hr., Suspend Mode = 1 hr., and HDD Power Down = 15 min.
Max. Power Saving	Maximum power management -- ONLY AVAILABLE FOR SL CPU's . Doze Mode = 1 min., Standby Mode = 1 min., Suspend Mode = 1 min., and HDD Power Down = 1 min.
User Defined	Allows you to set each mode individually. When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Initial display power management signaling.

Video Off In Suspend

This determines the manner in which the monitor is blanked.

The Choice: Yes, No.

SuspendType

Select the Suspend Type.

The Choice: PWRON Suspend, Stop Grant.

Suspend Mode

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

The Choice: 1Min, 2Min, 4Min, 8Min, 12Min, 20Min, 30Min, 40Min, 1Hour, Disabled.

HDD Power Down

When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

The Choice: 1Min, 2Min, 3Min, 4Min, 5Min, 6Min, 7Min, 8Min, 9Min, 10Min, Disabled.

Soft-off By PWR-BTTN

Instant-off allows the system to switch off immediately the power button is pressed. Otherwise, it will only so after you press the power switch for more 4 seconds.

Wakeup By PCI Card

When this option is set enabled, system will wakeup then wakeup event from PCI Card.

Wakeup On LAN (CSA GigaLAN)

When this option is set enabled, system will wakeup then power management event from on board LAN (INTEL82547).

Wakeup On LAN (I82562)

When this option is set enabled, system will wakeup then power management event from on board LAN (INTL82562ET).

Resume By Alarm

When this option is set enabled, system will according to you set time then wakeup from soft off mode.

4.10 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or **P**ersonal **C**omputer **I**nterconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

Phoenix - AwardBIOS CMOS Setup Utility		Item Help
PnP/PCI Configurations		Menu Level ▶
PNP OS Installed	[No]	Select Yes if you are using a Plug and Play capable operating system. Select No if you need the BIOS to configure non-boot devices.
Reset Configuration Data	[Disabled]	
Resources Controlled By	[Auto<ESCD>]	
PCI/UGA Palette Snoop	[Disabled]	

↑↓←→:Move Enter:Select +/-/PU/PD:Uvalue F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system can not boot.

The Choice: Enabled, Disabled .

Resource controlled by

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means

absolutely nothing unless you are using a Plug and Play operating system such as Windows®95. If you set this field to "manual" choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a "➤").

The Choice: Auto(ESCD), Manual.

PCI/VGA Palette Snoop

Leave this field at *Disabled*.

The Choice: Enabled, Disabled.

4.11 PC Health Status

Note: normal CPU Fan RPM is over than 5000 RPM. If your CPU Fan RPM is less than that figure, something is wrong and the CPU will be in overheat condition. Make sure that the connection at Fan1/Fan2 is correct.

Phoenix - AwardBIOS CMOS Setup Utility	
PC Health Status	
	Item Help
System Temperature	Menu Level ▶
CPU Temperature	
VCore <From VID>	
+1.5V	
+3.3V	
+5 V	
+12V	
- 12V	
Fan1 Speed	
Fan2 Speed	

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

4.12 Frequency/Voltage Control

Phoenix - AwardBIOS CMOS Setup Utility	
Frequency/Voltage Control	
CPU Clock Ratio [8 X]	Item Help
Auto Detect DIMM/PCI Clk [Enabled]	Menu Level ▶
Spread Spectrum [Disabled]	

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Auto Detect DIMM/PCI Clk

This item allows you to enable/disable auto detect DIMM/PCI Clock.

The Choice: Enabled, Disabled.

Spread Spectrum

This item allows you to enable/disable the spread spectrum modulate.

The Choice: Enabled, Disabled.

4.13 Load Fail-Safe Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Fail-Safe Defaults (Y/N) ? N

Pressing 'Y' loads the BIOS default values for the most stable, minimal-performance system operations.

4.14 Load Optimized Defaults

When you press <Enter> on this item you get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N) ? N

Pressing 'Y' loads the default values that are factory settings for optimal performance system operations.

4.15 Set Password

can enter and change the options of the setup menus.

ENTER PASSWORD:

Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED:

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer.

You determine when the password is required within the BIOS Features Setup Menu and its Security option (see Section 3). If the Security option is set to password will be required both at boot and at entry to Setup. If set to "Setup", prompting only occurs when trying to enter Setup.

4.16 Exit Selecting

Save & Exit Setup

Pressing <Enter> on this item asks for confirmation:

Save to CMOS and EXIT (Y/N)?

Pressing "Y" stores the selections made in the menus in CMOS – a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Exit Without Saving

Pressing <Enter> on this item asks for confirmation:

Quit without saving (Y/N)?

This allows you to exit Setup without storing in CMOS any change. The previous selections remain in effect. This exits the Setup utility and restarts your computer.

Appendix A. Watchdog Timer

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMI or a software bug. When the CPU stops working correctly, hardware on the board will either perform a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer:

INT 15H:

AH – 6FH
<u>Sub-function:</u> AL – 2 : Set the Watchdog Timer's period BL : Time-out value(Its unit--second or minute, is dependent on the item "Watchdog Timer unit select" in CMOS setup).

You have to call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer will start counting down. While the timer value reaches zero, the system will reset. To ensure that this reset condition does not occur, the Watchdog Timer must be periodically refreshed by calling sub-function 2. However the Watchdog timer will be disabled if you set the time-out value to be zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

Note: *When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system will reset.*

Example program:

```
; INITIAL TIMER PERIOD COUNTER
;
;
W_LOOP:
    MOV    AX, 6F02H    ;setting the time-out value
    MOV    BL, 30      ;time-out value is 48 seconds
    INT    15H
;
; ADD YOUR APPLICATION PROGRAM HERE
;
    CMP    EXIT_AP, 1  ;is your application over?
    JNE    W_LOOP      ;No, restart your application

    MOV    AX, 6F02H   ;disable Watchdog Timer
    MOV    BL, 0
    INT    15H
;
; EXIT
;
```

Appendix B. Address Mapping

IO Address Map

I/O address Range	Description
000-01F	DMA Controller
020-021	Interrupt Controller
040-05F	System time
060-06F	Keyboard Controller
070-07F	System CMOS/Real time Clock
080-09F	DMA Controller
0A0-0A1	Interrupt Controller
0C0-0DF	DMA Controller
0F0-0FF	Numeric data processor
1F0-1F7	Primary IDE Channal
2F8-2FF	Serial Port 2 (COM2)
378-37F	Parallel Printer Port 1 (LPT1)
3B0-3BB	Intel(R) 82865 Graphics Controller
3C0-3DF	Intel(R) 82865 Graphics Controller
3F6-3F6	Primary IDE Channal
3F7-3F7	Standard floopy disk controller
3F8-3FF	Serial Port 1 (COM1)

1st MB Memory Address Map

Memory address	Description
00000-9FFFF	System memory
A0000-BFFFF	VGA buffer
F0000-FFFFF	System BIOS
1000000-	Extend BIOS

*Default setting

IRQ Mapping Table

IRQ0	System Timer	IRQ8	RTC clock
IRQ1	Keyboard	IRQ9	AUDIO/SMBus Cntrlr
IRQ2	Available	IRQ10	LAN
IRQ3	COM2	IRQ11	LAN/USB2.0/SATA
IRQ4	COM1	IRQ12	PS/2 mouse
IRQ5	VGA/SMBus Cntrlr	IRQ13	FPU
IRQ6	FDC	IRQ14	Primary IDE
IRQ7	Available	IRQ15	Secondary IDE

DMA Channel Assignments

Channel	Function
0	Available
1	Available
2	Floppy disk (8-bit transfer)
3	Available
4	Cascade for DMA controller 1
5	Available
6	Available
7	Available

Appendix C.

How to Upgrade a New BIOS

<Note> Before flashing BIOS , please enable the item "FLASH BIOS" in BIOS setting.

You can install an upgrade BIOS for the SAGP-865EVG that you can download from the manufacturer's web site (<http://www.ieiworld.com>). New BIOS may provide support for new peripherals ,improvements in performance or fixes to addressed known bugs.

● BIOS Update Procedure:

1. Make a boot disk. Go to the DOS command prompt in MS-DOS or Windows 9x and, with an available floppy disk in "A", type "format A: /s" That will format the floppy and transfer the needed system files to it.
NOTES:
 - A. This procedure will erase any prior data on that floppy, so please Proceed accordingly.
 - B. Typically four files will be transferred, only COMMAND.COM being visible when running a simple directory listing.
 - C. Please leave the diskette UN-write protected for the balance of this procedure.
2. Download the BIOS upgrade file and awdflash.exe utility from a ICP web site to a temp directory on your hard drive, or directly to the floppy you made in step 1..
3. Copy (BIOS file and awdflash.exe)two files to the boot floppy.
4. Reboot the system to the DOS command prompt using the boot diskette you just made.
5. At the DOS command prompt type , "awdflash filename.xxx", where filename.xxx is the file name of the BIOS file . Hit enter.

6. Your first option, in sequence, will be to save the old BIOS. We recommend that you do that in case, for whatever reason, you decide you don't wish to use the new version once it is installed.
NOTES:
 - A. If you decide to save the old BIOS, PLEASE make sure you do NOT save it to the same file name as the new BIOS - if you use the same BIOS name the old file will be written over the new file with NO warning prompt. A simple file name to save the old BIOS to is OLDBIOS.BIN.
 - B. If you do NOT decide to save the old BIOS, PLEASE at least write down the version number of the old BIOS and store that information with your important computer documents. Enter N (for "no") and skip to step 9.
7. To save the old BIOS, hit Y (for "yes")
8. Enter a name for the OLD BIOS file and hit enter.
NOTE: PLEASE be sure you do NOT save the old BIOS file to the same file name as the new BIOS - if you use the same BIOS name, the old file will write over the new BIOS file WITHOUT a warning prompt. A simple file name for saving the old BIOS to is OLDBIOS.BIN.
9. Your second option, in sequence, will be whether you want to flash your BIOS. Enter Y (for "yes").
NOTE: This is the critical step. Once you hit the enter key, do NOT touch the keyboard, the reset button, or power switch while the flashing is in progress. There will be a bar progressing across the screen while the flashing is progressing.
10. When the flashing process is complete, you will be asked to reset or power off the system. Remove the floppy diskette from the floppy drive and either hit the reset button or the power button.
11. Reboot the system and note that the BIOS version on the initial boot-up screen has changed to the new BIOS version. Your BIOS upgrade is now complete.

- **Recovering Your Old BIOS:**

1. Assuming you have the floppy made during the upgrade procedure noted above, boot the system with that diskette in the floppy drive. If you do not have floppy made during the upgrade procedure noted above, you will need to repeat steps 1 through 3 (above) for the version of the BIOS you wish to recover to.
2. Complete steps 4, 5, 6B, 9, 10, and 11 (above) substituting the name of the BIOS you wish to recover for the upgrade BIOS at step 5.

Install screen :

<p style="text-align: center;">FLASH MEMORY WRITER U6.6 <C>Award Software 1998 All Rights Reserved</p>
<p style="text-align: center;">Flash Type -</p> <p>File Name to Program : <input type="text"/></p>
<p>Error Message:</p>

Appendix D. AGP slot

This IPC CPU Card has an Accelerated Graphics Port (AGP) slot that supports +1.5V AGP card. When you buy an AGP card, make sure that you ask for one with +1.5V specification. Note the notches on the card golden fingers to ensure that they fit the AGP slot on your ICP CPU card.

When SAGP-865EVG works with PCIAGP-4S or PCIAGP-5S backplane, please do not connect to an external AGP-VGA Card.

Appendix E.

Install Memory Modules

SAGP-865EVG has 2 dual in line memory module (DIMM) sockets . The BIOS will automatically detects memory type and size. To ins tall the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.

SAGP-865EVG supports the Dual Channel Technology. After operating the Dual Channel Technology, the bandwidth of Memory Bus will add double up to 6.4GB/s.

SAGP-865EVG includes 2 DIMM sockets, and each Channel has one DIMM socket.

If you want to operate the Dual Channel Technology, please note the following explanations due to the limitation of Intel® chipset specifications.

1. Only one DDR memory module is installed: The Dual Channel Technology can't operate when only one DDR memory module is installed.
2. Two DDR memory modules are installed (the same memory size and type): The Dual Channel Technology will operate when two memory modules are inserted individually into Channel A and B